#### StarHub - Typical Fibre Set Up Wireless Router **Power Sockets** Optical Network Terminal (ONT) LAN Cable Cat 5e or Cat 6/RJ45 **DECT phone Fibre Termination** Point (FTP) Fibre Cable/Patch Cord (attach to Optical port underneath ONT) (1)

#### StarHub Router Installation Guide







- First, switch off power to your ONT.
- Unplug and remove your old router from the ONT.
- Connect an Ethernet cable from the LAN port on your ONT to the Internet Port (yellow) of the Linksys EA7500 router.
- Plug the power back into your ONT. Please wait about one minute before continuing. Plug the power adapter into Linksys EA7500 and connect to an available power outlet or surge protector. If the Power LED (white Linksys) does not light up, press the Power button on the back of Linksys EA7500 router.
- Upon powering up the Linksys EA7500, the Linksys LED logo will stay in solid white once it has been booted up successfully.
- Scan for the wireless network name as listed on the supplied Wi-Fi configuration label at the bottom of the Linksys EA7500. Select the network and then enter the Wi-Fi password as stated on the label. Once connected, open the web browser in your laptop or mobile device, and type in  $\frac{\text{http://linksyssmartwifi.com or http://192.168.1.1}}{\text{http://linksyssmartwifi.com or http://192.168.1.1}}$
- A welcome page shall appear with the license agreement. Once you accept the license agreement, the Linksys EA7500 LED will indicate whether the Internet service is up or down.
- The Linksys LED will stay solid white when the Internet is up. It will blink in white when the Internet is down.
- Your Wi-Fi should now be working. Next create a Linksys Smart Wi-Fi account. Go to http://linksyssmartwifi.com. With your Linksys Smart Wi-Fi account, you will get access to Linksys Smart Wi-Fi tools and the Linksys app that will make your home network easier to manage and enjoy.

\*Please note that if you have your own CCTV/Security/PABX installation/Gaming/ other port forwarding setup in your home premises (current router), please refer to your specific vendor/provider for further assistance when you are replacing your current router with a NEW router.



#### Monitor and control your home Wi-Fi. Anytime. Anywhere - Download the Linksys Smart WiFi app

Download the Linksys App to your phone for easy set up. Follow the App instructions to complete set up.

#### **Quick and Easy Setup** Managing your home Wi-Fi with Linksys Smart Wi-Fi is fast and easy:











(3)

# - Download the Linksys Smart WiFi app

Monitor and control your home Wi-Fi. Anytime. Anywhere

## Download the Linksys App to your phone for easy set up. Follow the App instructions to complete set up.

(0)

Manage your home WiFi from any mobile device



connected to your home Wi-Fi

-0-

**ADVANCED SETTINGS** 


Connect Better







for all devices






and usage







- Enable Automatic Updates

and share home Wi-Fi

Wi-Fi network

(4)

To ensure you get the best performance from your router

http://www.linksys.com/us/wireless-routers/c/smart-wi-fi-wireless-routers/#fullstory

#### Upgrading the firmware of your router allows you to fully enjoy its complete features. It is especially important to update the firmware when installing your Linksys Smart Wi-Fi Routers for the first time to prevent a notification from prompting when you access some of the router and network settings again. If the setup wizard was used to configure your Linksys EA7500 automatic updates will be turned on by default.

You may, however, choose to manually enable automatic updates by following the steps below. **Enabling Automatic update** Keeping your home router updated is a crucial part of not just staying secure but to also enhance the performance of Managing your home Wi-Fi with Linksys Smart Wi-Fi is fast and easy:

Log in to your Linksys cloud account at www.linksyssmartwifi.com. Once the web



NOTE: If you don't have a Linksys cloud account, open a web browser and enter "http://myrouter.local" or "192.168.1.1" in the Address bar instead to access the router's interface.

interface opens, click Connectivity.

▶ Step 2: Under the Firmware Update section, check the box to enable the Automatic firmware update option. Once done, click Apply to save the changes.

Firmware Update When connected to



the internet, the router will be able to detect available updates for (Current Version: 1.1.26.140196) you to apply on your device.

your router. Security Features and Fixes Linksys may issue firmware updates to upgrade features such as outdated encryption modules or to add entirely new security mechanisms that weren't in previous versions of the firmware.

Performance Enhancements
Updating your Firmware can enhance your router's overall performance. If you don't update your firmware then you won't be able to take advantage of any speed boosting upgrades that Linksys might have released in an update.

#### For security reasons - Change Default Passwords

#### What is the Router Password for?

The Router Password is an administrator password used when accessing the router's web-based setup page. The default Router Password for all Linksys Smart Wi-Fi Routers is admin. However, it is recommended that you change the default password to a new and personalized one to ensure that the router is safe from unauthorized access.

▶ Step 1: Log in to your Linksys cloud account at www.linksyssmartwifi.com

Once the web interface opens, click Connectivity.

NOTE: If you don't have a Linksys cloud account, open a web browser and enter "http://myrouter.local" or "192.168.1.1" in the Address bar instead to access the router's interface.

▶ Step 2: Click Connectivity



▶ Step 3: Click Edit Router Password



▶ Step 4: Follow Instructions to change your password



For Additional information and how to videos visit the links below. http://www.linksys.com/fi/support-article?articleNum=142491 https://www.youtube.com/watch?v=tXIS9eObXuA



#### Troubleshooting

1. How can I reset the Linksys EA7500 to factory defaults?

There are **two (2)** ways to reset the Linksys EA7500 to factory defaults: **Hardware Reset** - Press and hold the Reset button on the back panel of the Linksys EA7500 for about

10 seconds. Software Reset - Log in to your Linksys Smart Wi-Fi Account. Under Router Settings, click Troubleshooting > Diagnostics. Click Reset under Factory reset.

2. I have reset the Linksys EA7500 and now I can't launch the setup page. What should I do?

You can try the following troubleshooting suggestions:

Access your Linksys Smart Wi-Fi account locally by opening your web browser and typing in <a href="http://192.168.1.1">http://192.168.1.1</a>. Input the admin password which is 'admin'.

If your computer has a static IP Address, make sure it has valid DNS numbers. If not, set the computer to obtain an IP address automatically.

QUICK TIP: Try again then, if needed, reassign a static IP Address back on on the computer.

3. What should I do if I can't connect to the Internet wirelessly and my network name is not listed in the Available Networks?

Try to perform the following steps to resolve the issue:

Verify that your router is ON and the Power logo is solidly lit.
 If you are far from the router, you might try moving closer to see if your device is out of the wireless

- network range
- Using a computer wired to the router, open the router's web-based setup page by entering "myrouter.local" or "http://192.168.1.1" and make sure that Broadcast SSID is ON. Turn the router OFF and power it back ON.

4. Can I also block HTTPS websites in Parental Controls?

Yes, website addresses starting with https:// can be blocked but, because they have encryption, the Linksys Smart Wi-Fi cannot redirect you. Instead of a page telling you the Address has been blocked, you will see a browser error page.

Additional FAQs and Troubleshooting information can be found at www.Linksys-SH.com



### Remote Assistance - Should you need more help

Linksys Smart Wi-Fi Agent Assist is a feature embedded inside the Linksys Smart Wi-Fi firmware, which will allow the customer to give permission to a Linksys Support Agent to take control and make changes to the router to help you with any issues you may encounter. Including Forwarding ports, setting up a network storage, or changing wireless settings.

#### Requirements

- Customer must have a Linksys Smart Wi-Fi account Customer must have an active Internet
- connection (WAN)



APORTANT NOTICE: In activating Agent Assist, the Linksys Support Agent ("Agent") will have access to Customer's Smart Wi-Fi account ettings but not to computer settings or any information stored on the computer, and the Customer's Wi-Fi network name and password will be



#### How to Optimize your Wi-Fi with the antennas The Linksys EA7500 Max-Stream™ AC1900 MU-MIMO Gigabit Wi-Fi Router comes with three external adjustable dual-band dipole antennas that provide powerful streams of data to multiple devices in a


single-story or multi-story home. The Linksys EA7500 external antennas feature: Large, overlapping Wi-Fi patterns for maximum signal strength and coverage Enhanced dual-band communication Antenna diversity for more robust connection with wireless clients



preference and network environment In order to optimize your antennas' maximum signal, the following positions are recommended:

All external antennas are adjustable to different positions depending on your

Optional Antenna Positioning





(9)

#### troubleshooting, FAQs, etc., please visit www.linksys-sh.com OR

You need more help?

For more information on the product, warranty, technical support,

scan the following QR code for easy access to the site:



Alternatively, you may call Linksys at: 6701-6971

25/5/17 11:52 am